


Applications are only to be used as a guide.
Please use a Spenic Taper set to select your cap / plug size.

Spenic Part Number	Known Applications
SP-1	
SP-2	
SP-3	
SP-4	
SP-5	Steering Pump
SP-7	
SP-6	AC Pump
SP-8	AC Pump – Turbo – Transfer Boxes
SP-9	ABS Modulator
SP-10	
SP-11	ABS Modulator - Steering Rack
SP-12	Steering Rack
SP-13	ABS Modulator – Steering Pump – Fuel Tank – Radiator – Steering Rack
SP-14	ABS Modulator – Steering Pump – Fuel Tank – Radiator – Steering Rack
SP-15	
SP-17	Steering Rack
SP-16	Steering Rack
SP-18	
SP-19	Steering Pump - Turbo
SP-20	
SP-21	
SP-22	Steering Rack
SP-23	AC Pump – Steering Pump – Turbo – Steering Rack
SP-24	
SP-25	
SP-26	
SP-27	AC Pump – Engine
SP-28	
SP-29	
SP-30	UK Battery (-)
SP-31	
SP-32	
SP-33	
SP-34	
SP-35	
SP-36	UK Battery (+)
SP-37	
SP-38	

Spenic Recycling, Unit 1, The Laurels, Stone, Berkeley, GL13 9LD, UK

T: 00 44 (0) 1454 430 209, M: 00 44 (0) 7703 194 697, E: cp@spenic-recycling.co.uk




Applications are only to be used as a guide.
Please use a Spenic Taper set to select your cap / plug size.

Spenic Part Number	Known Applications
SP-39	
SP-40	
SP-41	
SP-42	
SP-44	
SP-43	
SP-45	
SP-46	
SP-47	
SP-48	
SP-49	
SP-50	
SP-51	AC Pump
SP-52	AC Pump - Turbo
SP-53	
SP-54	Turbo
SP-55	
SP-56	
SP-58	Radiator – Gearbox – Engine – Transfer Box
SP-57	Radiator – Gearbox – Engine – Transfer Box
SP-59	
SP-61	Turbo
SP-60	
SP-62	
SP-63	
SP-64	
SP-65	
SP-66	
SP-67	Radiator – Engine – Turbo - Transfer Box
SP-68	
SP-69	
SP-70	
SP-71	Gearbox - Engine
SP-72	
SP-73	
SP-74	
SP-75	Turbo – Transfer Box
SP-76	

Spenic Recycling, Unit 1, The Laurels, Stone, Berkeley, GL13 9LD, UK

T: 00 44 (0) 1454 430 209, M: 00 44 (0) 7703 194 697, E: cp@spenic-recycling.co.uk




Applications are only to be used as a guide.
Please use a Spenic Taper set to select your cap / plug size.

Spenic Part Number	Known Applications
SP-77	
SP-78	
SP-79	
SP-80	
SP-81	Turbo
SP-82	
SP-83	
SP-84	
SP-85	
SP-86	
SP-87	Turbo
SP-88	Turbo
SP-89	Turbo
SP-90	
SP-91	
SP-92	
SP-93	
SP-94	
SP-95	
SP-96	
SP-97	
SP-98	
SP-99	
SP-100	
SP-101	
SP-102	
SP-103	
SP-104	
SP-105	
SP-106	
SP-107	
SP-108	
SP-110	
SP-109	
SP-111	
SP-112	
SP-113	
SP-114	
SP-115	
SP-116	

Spenic Recycling, Unit 1, The Laurels, Stone, Berkeley, GL13 9LD, UK

T: 00 44 (0) 1454 430 209, M: 00 44 (0) 7703 194 697, E: cp@spenic-recycling.co.uk



Applications are only to be used as a guide.
Please use a Spenic Taper set to select your cap / plug size.

Spenic Part Number	Known Applications
SP-117	
SP-118	
SP-119	
SP-120	
SP-121	
SP-122	
SP-123	
SP-124	
SP-125	
SP-126	
SP-127	
SP-128	
SP-129	
SP-130	
SP-131	
SP-132	

Spenic Recycling, Unit 1, The Laurels, Stone, Berkeley, GL13 9LD, UK

T: 00 44 (0) 1454 430 209, M: 00 44 (0) 7703 194 697, E: cp@spenic-recycling.co.uk

